

cinemizer^{OLED}



Operating instructions



Overview

Introduction	Requirements	1
	The multimedia video glasses	2
Overview	Contents of the package	3
	cinemizer ^{OLED} controls	4
	Battery box controls	5
Usage	Powering on	6
	Wearing comfort	7
	Nose pad adapter	7
	Ear clips	8
	Acuity adjustment	9
	Earpieces	10
	Stereo audio jack	12
	Volume	13
	Integrated battery	14
	Battery status	15
	Battery charging	17
	HDMI® connection	19
	iPod/iPhone and iPad connection (30 pin)	20
	iPod/iPhone and iPad connection (lightning)	21
	Other playback devices via cinch video cable	22
	Travel case	23
Additional functions	3D support	24
	3D formats supported	25
	OSD settings	28
	Activation of the OSD	28
	Navigation in the OSD	29
	Video	31
	Aspect	36
	Contrast	38
	Info	38
	Advanced	39
	Exit	41
Accessories	Adapter kit for iPod and iPhone (30 Pin)	42
	Headtracker (movement sensor)	43
	Light shield	45
Further information	Troubleshooting	46
	Technical support	46
Index		47

Introduction

Requirements

ATTENTION: For your own safety, read the complete instructions on the usage of the cinemizer® OLED multimedia video glasses in this manual, the safety information in the quick guide for the cinemizer® OLED multimedia video glasses (provided in the package and available from www.zeiss.com/cinemizer/documents) and the instructions for the devices to which the cinemizer® OLED multimedia video glasses are connected, before you use the cinemizer® OLED.

The following are required to use the cinemizer® OLED video glasses:

- A device with a USB connection for charging the battery, if necessary,
- A playback device, e.g. a computer, iPod/iPhone, gaming console, etc.
- A connection adapter (HDMI®, iPod/iPhone), or connection cable (3.5mm 4-pin jack to cinch)


! If a stationary image (e.g. a log-on screen or permanently displayed image/icon) remains on the screen for an extended period, you may still see it as a faint residual image, even after the image has been changed. This is termed "burn-in". For this reason avoid the playback of unchanging images! If faint residual images are visible, they can be eliminated by playing back varied content that fills the screen.

Registration

Please register at www.zeiss.com/cinemizer/registration to receive notifications directly when a firmware update is available.

The multimedia video glasses

As you look into the **cinemizer**^{OLED} video glasses you will obtain the visual impression of a television picture with a screen diagonal of 105 cm at a distance of 2 metres.



The ergonomic design and simple acuity adjustment between -5 and +2 dioptres for each eye make the **cinemizer**^{OLED} video glasses very convenient to wear, even for the wearers of spectacles.

The stereo 3D support converts the **cinemizer**^{OLED} multimedia video glasses into a portable 3D screen of universal application with which you can immerse yourself in virtual worlds.

cinemizer[®] OLED at a glance

Contents of the package

Travel case

Battery box

cinemizer-HDMI[®] adapter
(HDMI[®] mini jack type C)

HDMI[®] to mini HDMI[®]
Adapter cable

Mini USB cable

Video cable 3.5mm to 3 x cinch

cinemizer^{OLED}

Nose pad





Adapter A + B

Earpiece
with ear cap (medium)


Ear caps
(in 2 sizes
small/large)

Ear clip


Quick guide and safety instructions



cinemizer^{OLED} controls




Battery box controls




Usage

Powering on the cinemizer^{OLED} video glasses



Power on the **cinemizer^{OLED}** video glasses by briefly pressing the On/Off button until the mode and then the battery status LEDs illuminate. If an LED does not illuminate green after pressing the On/Off button, the battery is probably discharged and you should charge the battery for the **cinemizer^{OLED}** video glasses using a USB cable. If the battery has been fully discharged, it can take up to 15 minutes until the battery status LED starts to flash on charging the **cinemizer^{OLED}** via USB.



As long as video signal is not provided via the cinemizer HDMI[®] adapter or iPod/iPhone adapter, the text "**NO SIGNAL**" appears on the virtual screen in the multimedia video glasses. If a signal is not provided within 2 minutes of powering on, the **cinemizer^{OLED}** power off automatically (time out).

Powering off the cinemizer^{OLED} video glasses


If powered on, the **cinemizer^{OLED}** can be powered off by pressing the On/Off button. The battery status and video mode LEDs go out.

Nose pad adapter


The soft silicone nose pad adapter ensures you find it pleasant to wear the **cinemizer^{OLED}** glasses on your nose. Due to anatomical differences in the shapes of faces and noses, comfort can be improved using the optional nose pad adapters A and B.

The nose pad can be fastened in 3 different ways:


1) Nose pad without adapter



2) Nose pad with adapter A




3) Nose pad with adapter B




The simplest method is to try all 3 ways and decide which suits you best.

Ear clips


The ear clips for the **cinemizer**^{OLED} help both to securely attach the glasses to your head and to reduce the weight on your nose. You can then comfortably wear and use the **cinemizer**^{OLED} video glasses for an extended period.



Prior to putting on the **cinemizer**^{OLED} video glasses, please push the ear clips a little to the rear, put on the glasses and then push the ear clips from the rear to your ears.




! Prior to putting away the **cinemizer**^{OLED} multimedia video glasses in the travel case, you should remove the ear clips and place them loose in the travel case. In this way the ear clips are not subjected to mechanical forces that may irreparably damage them.



Acuity

The **cinemizer**^{OLED} video glasses offer stepless adjustment of the acuity in the range from -5 to +2 dioptres. In this way wearers of spectacles with the need for eyesight correction in this range can use the **cinemizer**^{OLED} video glasses without using their spectacles. Before you adjust the acuity, you should have adjusted the nose pad and the ear clips to suit you. You can continuously correct the dioptres separately for each eye using an adjustment wheel. However it is not possible to correct astigmatism.




! Please turn the adjustment wheel until the picture is sharp.
For this purpose close one eye while you make the adjustment for the other eye.

Earpieces


You can enjoy stereo sound with the **cinemizer^{OLED}** using the two earpieces.

1. Connect earpieces


The earpiece connectors are connected as shown in figures 1-3.




First the connector is loosely fitted in the 2.5mm jack, then pushed with the fingernail until it engages, and finally the cable pressed into the cable channel.



1
Insert connector loosely into the jack.




2
Push to the stop using your fingernail.




3
Press cable into the cable channel.

2. Use earpieces

With the glasses opened, please take the earpieces out of the magnetic storage clips and put on the **cinemizer**^{OLED} glasses. Please insert the earpieces in your ears.




The rubberised ear caps fitted to the earpieces are important for the correct seating of the earpieces.




Ear caps

Ear caps in three different sizes are included with the earpieces: small (S), medium (M) and large (L). Please try the different sizes and decide which size is most suitable for you. The medium-sized ear caps are fitted in the factory.

Proceed as follows to fit different size ear caps:




1
Pull the ear cap off the earpiece.




2
Push the different size ear cap onto the earpiece.

Stereo audio jack

If you want to use your own stereo earphones, you can connect them to the 3.5mm stereo audio jack provided.




In this case please remove the **cinemizer^{OLED}** earpieces as shown in the figure below.



Volume

You can change the volume of the **cinemizer**^{OLED} video glasses using the multifunction switch.



On the usage of an iPod or iPhone with the **cinemizer**^{OLED} glasses, the volume control on the iPod or iPhone is inhibited. On some iPod or iPhone models, the volume may still be indicated on the display if the volume buttons are actuated, but the volume in the **cinemizer**^{OLED} will not change.

! With an iPod or iPhone connected you can only adjust the volume on the **cinemizer**^{OLED}.

Each time you change the volume, the volume symbol will be displayed briefly on the virtual screen in the **cinemizer**^{OLED} glasses.



A total of 11 different volume settings and a mute setting are available. Each time you power on the **cinemizer**^{OLED} video glasses the volume is set to the default volume, which is 50% of the maximum volume.

Integrated battery

The integrated battery allows you to use the **cinemizer**^{OLED} glasses for up to 6 hours while you are travelling. The battery must have been fully charged prior to use. It takes approx. 2.5 hours to charge the battery.

Connection	Operating time in hours
Video cable	6
iPod/iPhone	6
HDMI®	2.5


Battery status

When the **cinemizer**^{OLED} is powered on, the battery status LED indicates to you the charge status of the battery. Low battery capacity is signalled by an orange (critical) or red (very critical) LED.

If the battery status LED illuminates red or orange, you should try to charge the battery using a USB cable.


Battery status LED Battery status

Illuminated red




The battery capacity is very low and therefore it is imperative the battery is charged. Depending on the playback device and the connection used (HDMI®, iPod, video), the battery will be able to supply power for max. 30 minutes.

Illuminated orange




The battery capacity is low and therefore the battery should be charged. Depending on the playback device and the connection used (HDMI®, iPod, video), the battery will be able to supply power for max. 60 minutes.

Illuminated green




The battery for the **cinemizer**^{OLED} video glasses is charged. Depending on the playback device and the connection used (HDMI®, iPod, video), the **cinemizer**^{OLED} can be operated portably for up to 6 hours.

If the battery charge drops below one of the two limits (orange, red) during operation, the related battery symbol will be displayed on the screen in orange or red.



With the **cinemizer**^{OLED} powered on, the battery symbol is also displayed briefly in the glasses if the volume is changed using the multifunction switch.




Battery charging

To charge the **cinemizer**^{OLED} battery you can connect the USB cable supplied to either a computer or a USB mains power supply plug. It is recommended to ensure the power source supplies at least 500 mA (e.g. USB 2.0).

While you charge the **cinemizer**^{OLED} battery, the battery status LED flashes. The colour of the flashing battery status LED indicates the battery capacity in 3 different colours.

If the battery is completely discharged, the battery status LED will not flash immediately when the video glasses are connected using a USB cable. Please leave the **cinemizer**^{OLED} video glasses connected to the PC via the USB cable for at least 15 minutes. Then disconnect the USB cable and connect again. The charging function is continued and the battery status LED illuminates.




The charging activity is indicated in the on-screen display by a progress bar in the battery symbol. This symbol is only visible if the volume is changed using the multifunction switch.

Battery status LED	Battery status
--------------------	----------------


Flashing red

The battery capacity is very low. After charging for approx. 40 minutes the colour of the battery status LED will change from red to orange.




Flashing orange

The battery charging status has reached a state that is sufficient for approx. 1-3 hours of operation depending on the playback device and the connection used.



Flashing green

The battery capacity is almost fully charged.




The battery is fully charged when the battery status LED no longer flashes, but instead is continuously illuminated green.

Please read the safety instructions on the rechargeable battery in the section "Safety and usage" in the short guide included in the package.

HDMI® connection

The **cinemizer**^{OLED} multimedia video glasses are supplied with a cinemizer-HDMI® adapter. Using this adapter the video glasses can be connected, e.g. to games consoles, Blu-ray players or **other** playback devices with an HDMI® interface.



Connect the HDMI® adapter to the battery box for the **cinemizer**^{OLED} and connect your playback device using an appropriate HDMI® cable. The jack on the cinemizer-HDMI® adapter is compliant with the mini HDMI® specification (type C). Please check the type (A, C or D) of HDMI® jack on the playback device before you purchase an HDMI® cable. Suitable HDMI® cables or adapters are available in any online electronics shop or electronics dealer.

The cinemizer-HDMI® adapter supports the following resolutions:


480p/576p
1280 x 720p 50/60Hz
1920 x 1080i 50/60Hz
1920 x 1080p 50/60Hz
1920 x 1080p 24Hz

In addition the 3D mode as per the HDMI® 1.4 specification for the resolutions 720p and 1080p is supported.

iPod/iPhone connection

To use the **cinemizer**^{OLED} multimedia video glasses with an iPod or iPhone an "Adapter Kit for iPod and iPhone" is available. This accessory kit, available from dealers or online shops (www.zeiss.com/cinemizer/shops), contains an adapter and a base plate with 3 retaining pads; these pads are placed one on top of the other on the base plate depending on the thickness of the iPod or iPhone model used. The **cinemizer**^{OLED} multimedia video glasses support all iPod and iPhone models capable of video playback.

The **cinemizer**^{OLED} multimedia video glasses support the "composite" and "component" video signals supplied by iPod and iPhone models. Depending on which video signal (576i, 480i, 576p, 480p) your iPod or iPhone supplies, the iPod/iPhone automatically communicates with the **cinemizer**^{OLED} video glasses to provide the best image quality.




Should the retention properties of the retaining pads become less effective, you should wash off particles of dirt from the retaining pads using a little soap and water. Please do not use brushes as these could damage the surface of the nano pads.

Connection of smartphones and tablets via MHL and Lightning


New iPod, iPhone and iPad models with the Lightning connector are not mechanically compatible with the cinemizer adapter kit for iPod and iPhone. Smartphones and tablets with, e.g., the Android or iOS operating system transmit the contents of the display digitally via an HDMI interface to the exterior.

These new Apple models profit from digital video transmission and can be connected to the **cinemizer**^{OLED} via HDMI using the Apple „Lightning Digital AV Adapter“. Other manufacturers of smartphones or tablets (e.g. Samsung, Motorola etc.) sell so-called MHL adapters that in turn permit connection to the **cinemizer**^{OLED} via HDMI. Exceptional image quality is achieved by the digital image transmission. Normally the complete contents of the display are also transmitted digitally to the **cinemizer**^{OLED} multimedia glasses, a feature that makes possible mobile video and also mobile gaming with breath-taking image quality.



Other playback devices via cinch video cable


All playback devices that output a "video composite" signal via the familiar yellow cinch jack can be connected (e.g. DVD players, mobile phones, smartphones, games consoles, multimedia hard disks, camcorders, digital reflect cameras, etc.) using the 3.5 mm AV-In jack integrated into the **cinemizer**^{OLED} battery box.



A video cable is required for this connection; this cable is included in the package and is available from dealers or online shops (www.zeiss.com/cinemizer/shops).

! Please note that the iPod/iPhone or HDMI adapter must be removed on playback via the AV-In jack!

On purchasing a video cable, it is **IMPERATIVE** you pay attention to the correct PIN assignment.




Travel case

To protect the **cinemizer**^{OLED} multimedia video glasses during transport, you can place them in the travel case supplied.


Prior to placing the **cinemizer**^{OLED} multimedia video glasses in the travel case, you should remove the ear clips and place them loose in the travel case. In this way the ear clips are not subjected to mechanical forces that may irreparably damage them.

Please proceed as follows:

1) First pull the ear clips off the two arms.




2) Place the glasses with the arms folded in the travel case.



3) Wind the cable around the glasses.

4) Place the black battery box with the adapter connected adapter and the ear clips removed previously on the **cinemizer**^{OLED} and close the travel case.




Additional functions

3D support

The **cinemizer**^{OLED} multimedia video glasses support real 3D. This feature is also termed stereo 3D or stereoscopic 3D.


A stereoscopic 3D video or image always contains 2 images:

1. The perspective from the point of view of the left eye and
2. The perspective from the point of view of the right eye.




On supply with 3D content with the 3D mode activated, the **cinemizer**^{OLED} displays the related image for the left and right eye. I.e. the images are separated as appropriate from the content played back and adapted for the left and right display.

After powering on the 2D video mode is set by default. You can change between the 2D and 3D video mode by pressing the multifunction switch for approx. 3 seconds.



The 3D mode is signalled by the blue mode LED.



If a device is connected via the HDMI® interface and this playback device **is able to provide** 3D via HDMI® 1.4 (frame packing), it is not possible to switch manually between 2D and 3D in the **cinemizer**^{OLED} glasses. In this case the playback device takes over the signalling of 2D or 3D content and the **cinemizer**^{OLED} switches over automatically. You must set whether you want 2D or 3D on the playback device, e.g. Blu-ray player, PS3 etc.

After switching over to the 3D mode, the 3D mode LED (🔵) illuminates and the 2D mode LED (🟢) goes out.

The following table shows the type of playback that supports 3D formats and the recommended formats.

Connection	Video source	Resolution	Video mode	3D format			
				Side-by-side	Top/bottom	Line interleave	HDMI® 1.4
External AV In	3.5 mm	720 x 576i	PAL composite	✓	-	-	-
		720 x 480i	NTSC composite	✓	-	-	-
iPod/iPhone adapter	iPhone (1G)	720 x 576i 720 x 480i	Component interlaced 576i / 480i	✓	-	-	-
	iPod touch 1G			✓	-	-	-
	iPod 5th gen			✓	-	-	-
iPod/iPhone adapter	iPhone 3G/3Gs	720 x 576p 720 x 480p	Component progressive 576p / 480p	✓	✓	-	-
	iPhone 4			✓	✓	-	-
	iPod touch 2G/3G			✓	✓	-	-
	iPod nano 3G - 5G			✓	✓	-	-
HDMI® adapter	HDMI® playback device	480p/576p	SD	✓	✓	-	-
		1280 x 720p 50/60Hz	HD ready 720p	✓	✓	-	-
		1920 x 1080i 50/60Hz	HD 1080i interlaced	✓	-	-	-
		1920 x 1080p 50/60Hz	Full HD 1080p	-	✓	✓	-
		1920 x 1080p 24Hz	Full HD 1080p24 (cinema)	-	-	-	-
		1920 x 1440p 60Hz	HDMI® 1.4 720p frame	-	-	-	✓
		1920 x 2160 24Hz	HDMI® 1.4 1080p frame	-	-	-	✓

Table 1 - 3D formats supported by the **cinemizer**^{OLED} multimedia video glasses (recommended 3D formats ✓)


The **cinemizer**^{OLED} video glasses save the last 3D format setting used.

You will find general information on the topic of "Stereo 3D" on the **cinemizer**^{OLED} homepage www.zeiss.com/cinemizer/3d.

If you activate the 3D mode with a long press on the multifunction switch, please ensure specially formatted 3D content is available and you have set the correct 3D format on the OSD.


The **cinemizer**^{OLED} multimedia video glasses do **not** convert normal films or games to 3D. The **cinemizer**^{OLED} multimedia video glasses support, depending on the playback and resolution, the following standard 3D formats:

a) **"Side-by-side"** — also known as "Parallel" The related stereo images are reduced to 50% of the original width so that both images fit in one video frame.




b) **"Top/bottom"**

The related stereo images are reduced to 50% of the original height so that both images fit in one video frame.




c) Line interleaved

The related stereo images are reduced to 50% of the original height so that both images fit in one video frame.



d) Frame packing

2 complete images
using frame packing
(HDMI® 1.4)





You can set the appropriate 3D format ("Side-by-side", "Top/bottom" or "Line interleaved") using the On-Screen Display (OSD). This does not apply for stereo 3D content provided via HDMI® using frame packing (HDMI® 1.4).

OSD settings

Activation of the OSD

You can change the settings for the multimedia video glasses using the integrated On-Screen Display (OSD). The on-screen display is a menu displayed in the virtual image generated by the video glasses.

You can activate the OSD by briefly pressing the multifunction switch.




The menu page on the left contains the main menu and the menu page on the right contains the settings menu. The green bar always indicates the actual position of the cursor, which is either on the main menu or on the settings menu.


If you do not undertake any actions with the OSD activated, the OSD disappears automatically after 7 seconds.

Navigation in the OSD




After activation of the OSD you can navigate up and down on the main menu by pushing the multifunction switch in the appropriate direction.





As you navigate up and down on the main menu, the current setting on the settings menu is displayed marked by a light-blue bar. To make settings in a specific menu item, please navigate to this point on the main menu and then press the multifunction switch.



The cursor then jumps from the main menu to the settings menu. Make the necessary settings on the settings menu by pushing the multifunction switch in the appropriate direction. The setting is applied by pressing once. With the exception of the two menu items "Horizontal Man. Adjust" and "Vertical Man. Adjust", the active cursor then changes back to the main menu.



If you do **not** want to make any changes or do **not** want to apply the changes, move the cursor to the "◀◀◀ Back" field and confirm by pressing the multifunction switch or wait until the OSD disappears after approx. 7 seconds.



In the case of the two menu items

- ◻ Man. Adjust,
- ◻ Man. Adjust,

the changes must be specifically confirmed using "Store settings".



If the changes are not confirmed using "Store settings" (by pressing the multifunction switch once), the changes are not applied.

Video

3D-Mode


The supported 3D formats are displayed on the settings menu for selection as a function of the device connected and the resolution used. If a device is not yet connected, it is not possible to change to the 3D mode settings menu. In this case this main menu item is not available.

! Important: the 3D formats supported depend on the resolution used and the playback device or adapter used. An overview of the 3D format supported is given in section 4 in "3D support".


If a 3D video played back in side-by-side or top/bottom in the **cinemizer^{OLED}** is not cleanly separated in the middle, a small amount of the image content for one eye will be seen in the other eye in the 3D mode. This problem can be corrected using the  "Horizontal Man. Adjust" function for side-by-side or  "Vertical Man. Adjust" for top/bottom.

Side-by-Side (L/R)

The default 3D mode is set to "Side-by-Side (L/R)", as this is the most common 3D format. With this format the left sub-image displays the perspective from the point of view of the left eye and the right sub-image the perspective from the point of view of the right eye.




Side-by-Side (L/R)




Side-by-Side (R/L)

With the format "Side-by-Side (R/L)" the perspectives are reversed compared to the previous 3D format.



Side-by-Side (R/L)




With both side-by-side variants (L/R and R/L) the related stereo images are reduced to 50% of the original width so that both images fit in one video frame.


An overview of the resolutions that support the 3D format side-by-side is given in the section "3D support".

Top/Bottom (L/R)

Another 3D format supported is the so-called "top/bottom" 3D format. With this format the perspectives (left/right) are arranged one above the other.




Top/Bottom (L/R)




Top/Bottom (R/L)

If the perspectives (left/right) of your 3D film or 3D game are arranged such that "top" forms the right perspective and "bottom" forms the left perspective, then please select the mode "Top/Bottom (R/L)".



Top/Bottom (R/L)




With both top/bottom variants (L/R and R/L) the related stereo images are reduced to 50% of the original height so that both images fit in one video frame.

An overview of the resolutions that support the 3D format top/bottom is given in the section "3D support".


Line interleaved

On the provision of "line interleaved" 3D content, the left and right perspectives are nested alternately in each other. I.e. a line with the left perspective is followed with a line for the right perspective etc.





Line interleaved (L/R)

If the left and right perspectives are reversed, you can select the format "Interleaved (R/L)" on the settings menu. In this case it is expected that a line for the right image is provided first followed by a line for the left image etc.




Line interleaved (R/L)




With both line interleaved variants (L/R and R/L) the related stereo images are reduced to 50% of the original height so that both images fit in one video frame.
An overview of the resolutions that support the 3D format line interleaved is given in the section "3D support".

HDMI® 1.4 - frame packing

In the case of HDMI® 1.4, unlike the previous 3D formats (side-by-side, top/bottom and line interleaved) 2 complete images are transmitted in the so-called "frame packing format". This is only possible using the standard HDMI® 1.4. If a film or game in 3D is provided via HDMI® 1.4, the 3D mode in the **cinemizer^{OLED}** video glasses is activated automatically. It is not possible or necessary to switch to the 3D mode, as the playback device signals whether the content is in 2D or 3D format. It is therefore not necessary to make any changes on the menu item "3D-Mode". In this case the settings menu is not available.



2 complete images using frame packing



Aspect

16 : 9

4 : 3

The aspect ratio defines the ratio between the lengths of the sides of the image for films or games. Using the "Aspect" menu you can set the aspect ratio for the image displayed. This setting is available for iPod and iPhone and in the case of playback via the AV video cable. But not in the case of HDMI®. The default setting is "Auto" and stands for automatic detection and setting. Normally signals are provided by the playback device that make it possible to identify the image aspect ratio for the film or game played. If this signal is not available, you can set manually the aspect ratio you prefer (16:9/4:3).

Auto

The **cinemizer**^{OLED} detects the aspect ratio signal defined by the playback device and adjust the aspect ratio correspondingly. If this aspect ratio signal is not available, the "4:3" aspect ratio is set automatically.

VIDEO
3D-Mode
Aspect
Contrast

INFO
Connection
Status

ADVANCED
Auto Adjust
Man. Adjust
Man. Adjust
Brightness Bal

EXIT

Auto
16 : 9
4 : 3
Zoom
◀◀◀ Back

16:9

With this setting you can change the aspect ratio to the wide screen format 16:9.

VIDEO
3D-Mode
Aspect
Contrast

Auto
16 : 9
4 : 3
Zoom
◀◀◀ Back

4:3


With this setting you can change the aspect ratio to 4:3.

VIDEO
3D-Mode
Aspect
Contrast

Auto
16 : 9
4 : 3
Zoom
◀◀◀ Back

Zoom

This setting enlarges the image horizontally and vertically. This setting is useful if you have Blu-ray films in the 21:9 format and as a result there are black bars at the top and bottom. This option can be switched on to see a full screen image. This setting is only possible with 1080p/24Hz.




- ! The aspect ratio can also be set on the majority of playback devices. Please read the related section in the manual for your playback device.
- If you are using an iPod and change the aspect ratio with the device connected and in operation, it is imperative you ensure the film or video is re-started, as a change in the aspect ratio during playback will not be detected by the iPod.

Contrast

The default setting is "Normal" and should provide the best image quality for the majority of applications.


In some films with very dark scenes, the setting "Film" should be selected to obtain better contrast in dark scenes.




Info

The two menu items **Connection** and **Status** contain general system parameters. Settings cannot be made here.

If you select **Connection**, you will see information on which signal is being played back over which interface to the **cinemizer^{OLED}**.



With the menu item **Status** selected you can see the system hardware and software version.




Advanced

The settings on the "Advanced" menu normally only need to be changed or modified in exceptional cases.

Auto Adjust


By activating the "Automatic Adjust" function the **cinemizer^{OLED}** is prompted to scan the input signal and adjust the image if necessary. This function is only supported in case of HDMI® playback.



Man. Adjust

If the separation of the left and right image is not exactly in the middle of the original video you can move the image horizontally using the manual adjustment function. This function is particularly useful in case of 3D playback in the format side-by-side. Select and confirm the "◀Shift◀" element to move the image to the left. Each time the function is confirmed the image moves one pixel to the left. Similarly with "▶Shift▶" the image moves one pixel to the right. The absolute shift is displayed in the line at the top, e.g. "Shift: +2pixel" and is visible in the background at the same time.


After changing the image position, it is **imperative** you confirm this change. For this purpose click the "Store Setting" field, the active cursor leaves the settings menu and changes to the main menu.



If you make changes, but do not explicitly confirm this change using "Store Setting", the changes are not applied when you leave the settings menu using "◀◀◀ Back" or if do not undertake any action for 7 seconds and as a result the OSD disappears automatically.

Man. Adjust


You can change the vertical position of the image using the function for the manual vertical adjustment. Select and confirm the "▲▲ Shift ▲▲" element to move the image upward. Each time the function is confirmed the image moves up one pixel. Similarly with each click on "▼▼ Shift ▼▼" the image moves down one pixel. The absolute shift is displayed in the line at the top, e.g. "Shift: +2 lines" and is visible in the background at the same time. After changing the image height, it is **imperative** you confirm this change. For this purpose click the "Store Setting" field, the active cursor leaves the settings menu and changes to the main menu.



If you make changes, but do not explicitly confirm this change using "Store Setting", the changes are not applied when you leave the settings menu using "◀◀◀ Back" or if do not undertake any action for 7 seconds and as a result the OSD disappears automatically.


Brightness Bal

If you should perceive different brightness on the two displays, you can increase or reduce the brightness to obtain displays with brightness that is subjectively the same. The two displays are set in the factory to the same brightness. For the manual change 6 brightness levels (+4%, +7%, +10%, -4%, -7%, -10%) are defined for the right display. As soon as you navigate to one of the pre-defined brightness levels, you can see the result already in the background. If you press the multifunction switch with a brightness level selected, this level will be applied.



Exit


If you want to leave the on-screen display, please navigate to and click the "Exit" field. If you do not undertake any further actions for more than 7 seconds with the on-screen display activated, the on-screen display disappears automatically.



Adapter kit for iPod and iPhone (30 Pin)

The adapter kit for iPod and iPhone is available as an accessory for the **cinemizer**^{OLED} and can be purchased from dealers and online shops. A list of current dealers is available at www.zeiss.com/cinemizer/shops.


In principle all iPod and iPhone models capable of playing back video are supported by the adapter kit. You will find more detailed information on this kit in the section "iPod/iPhone connection" in this document.



Headtracker (movement sensor)

The **cinemizer**^{OLED} Headtracker is connected to the computer via a standard USB connector and is immediately detected as a PC mouse by all common operating systems such as Windows, Linux and OS X; it is then ready to use. As a result the Headtracker is suitable for all applications that can be controlled using a computer mouse and it is possible to look around a virtual room with natural movements of the head. The **cinemizer**^{OLED} Headtracker features very fast reaction times and very little latency.

The **cinemizer**^{OLED} Headtracker is therefore particularly suitable for playing immersive games.




The **cinemizer**^{OLED} Headtracker is attached to the right arm of the video glasses and head movements are then detected by diverse sensors. Connect the Headtracker to a computer via USB and then do not move it for approx. 10 seconds. During this time the Headtracker undertakes a self-calibration.


The speed of the Headtracker can be set using an additional program (tray icon).

The software is available at www.zeiss.com/cinemizer/software.

A getting started guide is available for download at www.zeiss.com/cinemizer/documents.



For professional applications an SDK is available for direct access to the sensor data (raw data and quaternions) from the USB HID. In this way the sensor data from the 3rd rotation axis and absolute viewing angle information can also be used in applications.




To obtain the cinemizer headtracker SDK please fill in the web formular under www.zeiss.com/cinemizer/headtrackerSDK.

First name:	Last name:
<input type="text"/>	<input type="text"/>
Country:	Email:
<input type="text" value="Germany"/>	<input type="text"/>
I have already a cinemizer multimedia glasses	
<input type="radio"/> Yes <input type="radio"/> No	
Would you like to get the cinemizer headtracker SDK?	
<input type="radio"/> Yes <input type="radio"/> No	
Do you have a specific question about the headtracker? Please write it in the text field below.	
<input type="text"/>	
Field of application	
<input type="checkbox"/> Gaming	
<input type="checkbox"/> First Person View (FPV)	
<input type="checkbox"/> Immersive learning (eLearning / eTraining)	
<input type="checkbox"/> CAD visualization (e.g. architecture)	
<input type="checkbox"/> Other	
<input type="button" value="Submit"/>	

Light shield

The Eyeshield is an accessory for the **cinemizer**^{OLED} video glasses that shields the user from the outside world.



The flexible insert made of soft rubber and plastic can be straightforwardly attached to the multi-media glasses and completely encloses the area around the eyes.

If you use the **cinemizer**^{OLED} for instance as an external viewfinder or to watch films on the move, sunlight and other sources of interference from the outside are completely excluded.

On playing games the outside world is completely shut out by the light shield and the player can intensively immerse completely in virtual worlds.

Further information


You will find comprehensive information on the multimedia video glasses on the website www.zeiss.com/cinemizer

cinemizer^{OLED} support website

You can read frequently asked questions related to the **cinemizer^{OLED}** and their answers at www.zeiss.com/cinemizer/faq.

Technical support

Before you contact technical support with technical questions, please make sure you have first read through the questions on the FAQ page. Should your questions still not have been answered, please contact technical support. For this purpose go to www.zeiss.com/cinemizer/support and complete the related form.



The screenshot shows the Zeiss website's support page for the cinemizer OLED. At the top, there is a navigation bar with the Zeiss logo, a 'Find a dealer' link, and a 'Product registration' link. Below this is a secondary navigation bar with links for 'cinemizer OLED', 'Product Information', 'Applications', 'Media Center', and 'Support'. A breadcrumb trail reads 'Home / Support / Contact'. The main heading is 'Contact'. A paragraph of text advises users to read the FAQs before contacting support. Below this is a link to 'General questions and answers'. The form itself consists of several fields: a large text area for 'Your inquiry', followed by 'First name' and 'Last name' fields, 'Email' and 'Country' fields (with a dropdown for country), a 'Your cinemizer' dropdown menu (with 'Please select' as the current option), and a 'Your cinemizer serial number (e.g. H225A0069)' text field.

2D/3D mode display	5, 25	Ergonomic comfort	2, 4, 9
3D format	25, 31	Exit	41
3D mode	31	Eyeshield	45
3D support	2, 24	Firmware version	38
Accessories	42	Games console	1, 19
Activation of the OSD	28	Hardware version	38
Acuity adjustment	4, 9	HDMI® adapter (HDMI® 1.4)	3, 5, 19
Adjustment wheel	4, 9	HDMI® adapter cable	3, 19
Aspect ratio	36	Headtracker	43
Aspect	36	Image adjustment	36
Auto Adjust	39	Image resolution	25
AV-In jack	5, 22, 25	Info	38, 46
Battery box controls	5	iPod/iPhone adapter	5, 20, 25
Battery box	3, 5, 9, 18, 19, 20, 22, 23	iPod/iPhone	6, 14, 20, 42
Battery operating time	14	Line interleaved	27, 34, 35
Battery status LED	5, 6, 15, 17, 18	Manual Adjust	30, 39, 40
Battery status	15, 17	Menu	28
Battery symbol	16, 17	Mini USB cable	3
Blu-ray player	19, 25, 37	Mini USB jack	5
Brightness Balance	40	Mode LED	5, 6, 25
Charging battery	1, 5, 6, 15, 16, 17, 18	Multifunction switch	5, 13, 16, 25, 28
Charging status	17	Muting	13
Charging/battery status display	5, 6, 15, 17	Navigation in the OSD	29
Cinch jack	22	Nose pad	3, 4, 7
Cinch video cable	22	Nose pad adapter	3, 7
cinemizer controls	4	On/Off button	5, 6
cinemizer socket	5	OSD settings	28
Connection	1, 5, 15, 18, 19, 25	Playback device	5, 15, 18, 22, 25, 31, 36
Connection	38	Powering off	6
Contents on the package	3	Powering on	6, 13, 25
Default volume	13	Putting into use	6
Dioptr correction	9	Reset button	5
Ear cap	3, 11	Short Guide	3
Ear clip	4, 8, 23	Side-by-side	25, 31
Earpiece	3, 4, 10, 11, 12	Status	38
Earpiece jack	5	Stereo audio connector	12
Earpiece storage clip	4, 11	Stereo audio jack	12
Earpiece	4, 10, 11, 12	Stereo earphones	12

Technical support	46
Top/bottom	25, 31, 33
Travel case	3, 8, 23
Troubleshooting	46
USB cable	3, 6, 15, 17
USB mains power supply plug	17
Video cable PIN assignment	21
Video cable	3, 14, 22, 36
Video mode	25
Video	31
Viewing window	4
Volume symbol	13
Volume	5, 13, 16, 17

iPhone and iPod are trademarks of Apple Inc., registered in the U.S. and other countries.

"Made for iPod" and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod or iPhone may affect wireless performance.

HDMI[®], the HDMI[®] logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI[®] Licensing LLC in the United States and other countries.

© Copyright Carl Zeiss AG 2012
cinemizer^{® OLED} is a registered trademark of Carl Zeiss
Designed by Carl Zeiss Germany

Carl Zeiss AG
Carl-Zeiss-Strasse 22
73447 Oberkochen
www.zeiss.de/cinemizer

